

iGS-021
User Guide V1.3

IGS-021 **D&N T° Control**
User Guide

The unit has to sense some light to operate in day mode and needs 5 sec. to detect day/night transitions.

To set day and night temperatures : Align DAY and NIGHT knob markers to desired temperatures.

To change from heating to COOLING : disconnect the unit from the power outlet, turn both knobs fully clockwise (beyond the last line on scale), reconnect the unit, immediately turn both knobs fully counter clockwise and wait 2 seconds; then readjust your Day and Night knobs for normal cooling operation.

To change from cooling to HEATING : same as above with the following difference : start with knobs fully counter clockwise, power up and then immediately turn both knobs to fully clockwise and wait 2 seconds. Then readjust your Day and Night knobs for normal heating operation.

The Cooling/Heating setting is saved into the thermostat.